

# ***DESIGN AND MANAGEMENT CONSIDERATIONS FOR SUBSURFACE DRIP IRRIGATION SYSTEMS***

**Freddie R. Lamm**  
Research Agricultural Engineer  
Northwest Research-Extension Center  
Colby, Kansas

**Danny H. Rogers**  
Extension Agricultural Engineer  
Department of Agricultural Engineering  
Manhattan, Kansas

**William E. Spurgeon**  
Research Agricultural Engineer  
Southwest Research-Extension Center  
Garden City, Kansas

**Kansas State University**

## **INTRODUCTION**

Every project must have a goal. This goal should be solidly grounded with a purpose. It makes little sense to achieve a goal if the purpose has not been satisfied. If the goal of the irrigator is to develop and operate a successful subsurface drip irrigation (SDI) system, what is the purpose? Water conservation and water quality protection have often been cited as possible purposes to consider SDI. If so, it is imperative that the SDI system be designed and operated in a manner that there is a realistic hope to satisfy those purposes. It should also be noted that an improperly designed SDI system is less forgiving than an improperly designed center pivot sprinkler system. Water distribution problems may be difficult or impossible to correct for an improperly designed SDI system.

This material is based upon work supported by the U. S. Department of Agriculture Cooperative State Research Service under Agreement No. 93-34296-8454.

Any opinions, findings, conclusions or recommendations expressed in this publication are those of the authors and do not necessarily reflect the views of the U. S. Department of Agriculture.

The mention of trade names or commercial products does not constitute their endorsement or recommendation by the authors, the Kansas Agricultural Experiment Station, or by the U. S. Department of Agriculture.

## HYDRAULIC DESIGN

Successful operation of a SDI system begins with a proper hydraulic design which will satisfy the constraints dictated by crop, soil type and characteristics, field size, shape, and topography, and water source and supply. Disregarding design constraints will likely result in a system that is costly in both time and money to operate and will likely increase the chance of system failure. System failure might result in the loss of the total capital investment.

### Crops and Soils Considerations

The crop and soil type will dictate SDI system capacity, dripline spacing, emitter spacing, and installation depth. The SDI system capacity must be able to satisfy the peak water requirement of the crop through the combination of the applied irrigation amount, precipitation, and stored soil water. The system capacity will influence the selection of the dripline flowrate and the zone size (area served by each submain). Improper selection of these items can result in more expensive systems to install and operate.

The dripline spacing is obviously an important factor in system cost, and economics suggest wider spacings. However, wide spacing will not uniformly supply crop water needs and will likely result in excess deep percolation on many soil types. The dripline spacing is dictated by the lateral extent of the crop root zone, lateral soil water redistribution, and in-season precipitation. Studies on silt loam soils in western Kansas conducted by Kansas State University have indicated that a 60-inch dripline spacing is optimal for a corn-row spacing of 30 inches. Soils that have a restrictive clay layer below the dripline installation depth would probably allow a wider dripline spacing without affecting crop yield. Wider spacings may also be allowable in areas of increased precipitation as the dependency of the crop on irrigation is decreased. The emitter spacing is dictated by the same factors affecting dripline spacing. However, generally, the emitter spacing is less than the dripline spacing. As a rule of thumb, dripline spacing is related to crop row spacing while emitter spacing is more closely related to crop plant spacing. One of the inherent advantages of a SDI system is the ability to irrigate only a fraction of the crop root zone. Careful attention to dripline spacing and emitter spacing are, therefore, key factors in achieving the purpose of water conservation and water quality protection.

The installation depth is also related to the crop and soil type. Deep installations reduce the potential for soil evaporation and also allow for a wider range of tillage practices. However, deep installations may limit the effectiveness of the SDI system for seed germination and may restrict availability of surface-applied nutrients. Acceptable results have been obtained with installation depth of approximately 18 inches in KSU studies in western Kansas on deep silt loam soils. Dripline should probably be installed above any restrictive clay layers that might exist in the soil. This would help increase lateral soil water redistribution.

## Field Size, Shape, and Topography

The overall field size may be limited by the available water supply and capacity. The ability to economically adjust the size of the irrigated field to the available water supply is a distinct advantage of SDI systems compared to center pivot sprinkler systems. If sufficient water supply is available, the field size, shape, and topography, along with the dripline hydraulic characteristics, will dictate the number of zones. Minimizing the number of necessary zones will result in a more economical system to install and operate.

Whenever possible, dripline laterals should be installed downslope on slopes of less than 2%. On steeper terrain, the driplines should be made along the field contour and/or techniques for pressure control should be employed.

## Dripline Hydraulic Characteristics

Pressure losses occur when water flows through a pipe due to friction. These friction losses are related to the velocity of water in the pipe, the pipe inside diameter and roughness, and the overall length. The emitter flowrate (Q) can generally be characterized by a simple power equation

$$Q = k H^x$$

where k is a constant depending upon the units of Q and H, H is the pressure and x is the emitter exponent.

The value of x is typically between 0 and 1, although values outside the range are possible. For an ideal product, x equals 0, meaning that the flowrate of the emitter is independent of the pressure. This would allow for high uniformity on very long driplines, which would minimize cost. An emission product with an x of 0 is said to be fully pressure compensating. An x value of 1 is noncompensating, meaning any percentage change in pressure results in an equal percentage change in flowrate. Many lay-flat drip tape products have an emitter exponent of approximately 0.5. A 20% change in pressure along the dripline would result in a 10% change in flowrate if the exponent is 0.5. As a rule of thumb, flowrates should not change more than 10% along the dripline in a properly designed system. Most manufacturers can provide the emitter exponent for their product. Irrigators would be well advised to compare the emitter exponent among products and be wary of manufacturers that cannot provide this information.

Friction losses increase with length of run (Figure 1). For this example, the dripline has a design flowrate of 0.25 gpm/100 ft. at 10 psi on a level slope. The variation in flows,  $Q_{var}$ , are 6, 16, and 29% for the 400, 600 and 800 ft. runs, respectively. Using general criteria for  $Q_{var}$ , these systems would be classified as desirable, acceptable, and not acceptable (Table 1).




Figure 1. Calculated dripline flowrates on level slopes as affected by length of run. Data from Chapin Watermatics<sup>1</sup>.

Table 1. Dripline Uniformity Criteria

	Flow variation, $Q_{var}$	
Desirable	< 10%	
Acceptable	10 - 20%	
Unacceptable	> 20%	
	Statistical Uniformity	Emission Uniformity
	U	$E_u$
Excellent	95-100%	94-100%
Good	85-90%	81-87%
Fair	75-80%	68-75%
Poor	65-70%	56-62%
Unacceptable	< 60%	< 50%

Friction losses also increase with the velocity of water in the dripline. For a given inside diameter of line, friction losses will be greater for driplines with higher flowrates (Figure 2). Some designers prefer higher capacity driplines because they are less subject to plugging and allow more flexibility in scheduling irrigation. However, if larger-capacity driplines are chosen, the length of run may need to be reduced to maintain good uniformity. Additionally, the zone area may need to be reduced to keep the flowrate within the constraints of the water supply system. Decreasing the length of run or the zone area increases the cost of both installation and operation.




Figure 2. Calculated dripline flowrates on level slopes as affected by dripline capacity. Data from Chapin Watermatics<sup>1</sup>.

The land slope can have either a positive or negative effect on the pressure distribution along the dripline lateral (Figure 3). Irrigating uphill will always result in increasing pressure losses along the lateral length. If the downhill slope is too large, the flowrate at the end of the line may be unacceptably high. In the example shown, the most optimum slope is either 0.5 or 1.0% downslope. Both slopes result in a flowrate variation of approximately 10% for the 600 ft. run.




Figure 3. Calculated dripline flowrates as affected by slope. Data from Chapin Watermatics<sup>1</sup>.

The preceding discussion has only dealt with theoretical calculations that don't take into account the variability in manufacturing. The coefficient of manufacturing variation,  $C_v$ , is a statistical term used to describe this variation. Some dripline products are inherently difficult to manufacture with consistency and, therefore, may have a high  $C_v$ . Other products may suffer from poor quality control. The American Society of Agricultural Engineers (ASAE) has established  $C_v$  ranges for line-source driplines. A  $C_v$  of less than 10% is considered good; from 10 to 20%, average; and greater than 20%, marginal to unacceptable. The  $C_v$  of a product should be obtained from the manufacturer to aid in decisions regarding suitability of the product for a particular installation.

There are two additional terms to describe system uniformity that can be calculated for a SDI system. They are the emission uniformity  $E_u$  and the statistical uniformity  $U_s$ . The calculations of the terms lies beyond the scope of this discussion, but they may be encountered in the process of developing a SDI system. The criteria for evaluating these uniformities as developed by the ASAE are listed in Table 1.

## FILTRATION, FLUSHING, AND WATER TREATMENT

Plugging of the dripline emitters is the major cause of system failure. Plugging can be caused by physical, chemical, or biological materials. The filtration system is one of the most important components of the SDI system. Its operation and maintenance must be well understood by the irrigator to help ensure the longevity of the SDI system. There are many different types of filtration systems used with SDI systems. The type is dictated by the water source and also by the emitter size. Improper filter selection can result in a SDI system which is difficult to maintain and a system prone to failure. The filtration system can be automated to flush at regular time intervals or at a set pressure differential.

Screen or sand media filters are used to remove the suspended solids (physical) such as silt, sand, and organic and inorganic debris from the water. Surface water often requires more extensive filtration than groundwater, but filtration is required for all systems.

Chemical reactions in the water can cause precipitates, such as iron or calcium deposits to form inside the driplines. Plugging can be caused by either natural water conditions or by chemicals such as fertilizer added to the water. To avoid chemical clogging, the water must be analyzed to determine what chemicals are prevalent and which chemical additives should be avoided. Chemical water treatment may be required on a continuous or intermittent basis. Acids are sometimes used to prevent plugging and also to help renovate partially plugged driplines. The need for treatment is dictated by the water source and the emitter size. A thorough chemical analysis of the water source should be made prior to development of the SDI system.

Biological clogging problems may consist of bacterial slimes and algae. Some problems can be eliminated in the filtration process, but injection of chlorine into the driplines on a periodic basis is required to stop the biological activity. The source and composition of the water will determine, to a large extent, the need for chlorination.

A flushing system is recommended at the distal end of the dripline laterals to assist in removing sediment and other materials that may accumulate in the dripline during the season. This is in addition to a proper filtration system. A useful way to provide for flushing is to connect all the distal ends of the driplines in a zone to a common submain or header which is called the flushline. This allows the flushing to be accomplished at one point. Two other distinct advantages exist for this method. If a dripline becomes plugged or partially plugged, water can be provided below the plug by the interconnected flushline. Additionally, if a break in the dripline occurs, positive water pressure on both sides of the break will limit sediment intrusion into the line.

## MANAGEMENT CONSIDERATIONS

A thorough discussion of the management for SDI systems lies beyond the scope of this paper. However, a brief discussion with regards to system longevity and also with regards to satisfying the stated purposes is in order.

Managing a SDI system is not necessarily more difficult than managing a furrow or sprinkler irrigation system, but it does require a different set of management procedures. Improper management of a SDI system can result in system failure, which might mean the loss of the total capital investment. Proper day-to-day management requires the operator to evaluate the performance of the components, to determine crop irrigation needs, and to make adjustments as needed. The performance of the SDI system components can be evaluated by monitoring the flowrate and pressures in each zone. Pressure gages should be installed on riser pipes from the submain and flushline at each of the four corners of the zone. Comparison of the flowrate and pressures from one irrigation event to the next can reveal any problems that are occurring. For instance, if the flowrate has increased and the pressure is lower, the irrigator needs to investigate for a possible leak in the system. Conversely, if the flowrate is lower and the pressure is higher, the irrigator needs to check the filtration system or look for possible plugging. Disregarding day-to-day management can result in problems such as poor water distribution, low crop yields, and even system failure.

SDI systems are typically managed to apply small amounts of water on a frequent basis to the crop. If properly managed, there are opportunities to save water and to provide a more consistent soil water environment for the crop. However, irrigation scheduling must be employed as some of the visual indicators of overirrigation, such as runoff, no longer exist with this type of irrigation. Overirrigation with a SDI system can lead to reduced yields because of aeration problems exacerbated by the higher irrigation frequency and also perhaps by the more concentrated crop root system. Overirrigation can dramatically increase deep percolation, which can increase groundwater contamination.

SDI systems are often used to provide all or a portion of the crop nutrient needs. The ability to spoon feed the crop its nutrients reduces the potential for groundwater contamination. However, fertigation is only recommended on SDI systems with good or excellent uniformity. Irrigation and nutrient amounts must be managed together to prevent leaching.

## CONCLUDING STATEMENT

The initial investment costs for a SDI system are high, which may limit their use on field crops with relatively low value. Efforts are justified to minimize, investment costs whenever possible and practical. However, if water conservation and water quality protection are the purposes of using the system, proper design procedures must be employed. The SDI system must also be properly designed to ensure system longevity. Minimizing investment costs through cheaper designs can be a double-edged sword, as a cheaper system may increase operating costs and/or possibly increase the chance of system failure.






Figure 3. Calculated dripline flowrates as affected by slope. Data from Chapin Watermatics<sup>1</sup>.

The preceding discussion has only dealt with theoretical calculations that don't take into account the variability in manufacturing. The coefficient of manufacturing variation,  $C_v$ , is a statistical term used to describe this variation. Some dripline products are inherently difficult to manufacture with consistency and, therefore, may have a high  $C_v$ . Other products may suffer from poor quality control. The American Society of Agricultural Engineers (ASAE) has established  $C_v$  ranges for line-source driplines. A  $C_v$  of less than 10% is considered good; from 10 to 20%, average; and greater than 20%, marginal to unacceptable. The  $C_v$  of a product should be obtained from the manufacturer to aid in decisions regarding suitability of the product for a particular installation.

There are two additional terms to describe system uniformity that can be calculated for a SDI system. They are the emission uniformity  $E_u$  and the statistical uniformity  $U_s$ . The calculations of the terms lies beyond the scope of this discussion, but they may be encountered in the process of developing a SDI system. The criteria for evaluating these uniformities as developed by the ASAE are listed in Table 1.